


# HOW TO CHANGE TEMPERATURE SCALE

INSTRUCTIONS FOR **Carrier** BRAND EQUIPMENT



1

On the keypad,  
press **CODE  
SELECT**.

2

Press the arrow  
up or down  
until you see  
**Cd28**, then  
press **ENTER**.

3

Wait until you see the  
C or F blinking, then use  
one of the arrow keys to  
switch from C to F, or  
from F to C.  
Press **ENTER** within 5  
seconds to set the  
selected scale.  
The temperature scale is  
now changed.



**Tropical**  
SHIPPING

For further assistance,  
call one of the following  
telephone numbers.

**Business Hours**  
561-840-2949

**After Hours**  
561-762-4266  
561-373-4479  
561-307-6638  
561-373-0878

[www.tropical.com](http://www.tropical.com)